


FIG. 1






FIG. 3

Start Time	00 11:0	nt Ev #	nt Ev	/ TV	/ TV nt Ev
	9:00 10:00	TV TV Event #1 #1	TV TV Event #2 #2	TV TV Event #4	TV TV TV Event #6 #7
	8: 00	TV Event I	TV Event I	;	TV Event II
Channel		200	501	502	503




FIG. 5

ROC919990202US2 6/18 __600 601-Start 602 Select Currently Highlighted Entry -603 Has **User** Requested Yes Not to be Disturbed *605* < No Instruct Modem Not to Ring 604 Room Phone Perform Other Set Top Box 606 **Functions** Set Do Not Disturb Flag to True 607 Generate Timer Based on End Time of Selected Television Event 608 Save End Time of Selected Television Event

FIG. 6




FIG. 7

ROC919990202US2 8/18 ___800 *801*-**Start** -802 ls Ring Detected Yes Nο on Telephone Line 803 ls DND Flag No Yes Set 804 806 **Answer Call** ls Number Yes No of Rings Exceeded 805 **Play Greeting** Indicating when Television Event Ends 807 **Answer Call** 808 **Play Greeting**

Fig. 8A Fig. 8B

FIG. 8A




FIG. 8B






FIG. 9

Serial No.: 10/816,705; Art Unit: 2623 Replacement Sheet ROC919990202US2 11/18 ___1000 1001 **Start** 1002 Are There Any Yes Unreviewed Priority Messages -1003 No Prompt User to Press Button 1004 Wait for Button to Be Pressed 1005 Play Unreviewed Priority Messages Over Television Set 1006 Start Message Center Background Task 1007 Perform Normal Set Top Box Start-up Operations End

FIG. 10

1008





FIG. 11

Replacement Sheet

ROC919990202US2






FIG. 12B




FIG. 12C




FIG. 12D




FIG. 12E

ROC919990202US2 18/18 1301-- 1300 Start 1302 Has 1303 Set Top Box Yes End Been Re-Enabled No 1304 Disable Set Top Box -1305 Display Dialog Box Requesting Password -1306 1310 Did Has Calling Party Password Been No No Request TV Set Be Received Re-Enabled ? Yes Yes 1307 ls No **Password Correct** Yes 1308 Re-Enable Set Top Box

FIG. 13

1309

End